



SMART CLOCK (BSA, BRS, MRS SERIES) SETTING INSTRUCTIONS



THERE ARE NINE REGISTERS.
THE **(DISPLAY)** BUTTON WILL MOVE YOU THROUGH THESE REGISTERS.
USE THE **(SET 1)** AND **(SET 2)** BUTTONS TO SET THE REGISTERS..

- STEP 1:** REAL TIME DISPLAY.
THE **(SET 1)** BUTTON ADVANCES THE MINUTES AND THE **(SET 2)** BUTTON ADVANCES THE HOURS.
NOTE: WHEN ADVANCING THE MINUTES, THE SECONDS ARE ZEROED.
- STEP 2:** PRESS THE **(DISPLAY)** BUTTON TO SHOW THE MONTH AND DAY.
THE **(SET 1)** BUTTON ADVANCES THE DAY AND THE **(SET 2)** BUTTON ADVANCES THE MONTH.
- STEP 3:** PRESS THE **(DISPLAY)** BUTTON TO SHOW THE YEAR.
THE **(SET 1)** BUTTON INCREASES THE YEAR AND THE **(SET 2)** BUTTON DECREASES THE YEAR.
- STEP 4:** PRESS THE **(DISPLAY)** BUTTON TO SHOW THE 12 OR 24 HOUR FORMAT.
THE **(SET 1)** BUTTON SETS 12 OR 24 HOUR.
- STEP 5:** PRESS THE **(DISPLAY)** BUTTON TO SHOW THE DAYLIGHT SAVING TIME CODE.
THE **(SET 1)** BUTTON INCREASES AND THE **(SET 2)** BUTTON DECREASES THE DST CODE SETTING.
SEE: <https://digitaldisplay.com/zones-maps-dst-instructions-v-2-rel-before-jul-15-2019/>
<https://digitaldisplay.com/zones-maps-dst-instructions-v-3-jul-15-2019-and-on/>
- STEP 6:** PRESS THE **(DISPLAY)** BUTTON TO SHOW THE ZONE CODE.
THE **(SET 1)** BUTTON INCREASES AND THE **(SET 2)** BUTTON DECREASES THE ZONE NUMBER.
NOTE: A (7) IS DISPLAYED ON THE FAR LEFT TO IDENTIFY THE ZONE REGISTER.
SEE: <https://digitaldisplay.com/zones-maps-dst-instructions-v-2-rel-before-jul-15-2019/>
<https://digitaldisplay.com/zones-maps-dst-instructions-v-3-jul-15-2019-and-on/>
- STEP 7:** PRESS THE **(DISPLAY)** BUTTON TO SHOW THE BRIGHTNESS.
THE **(SET 1)** BUTTON INCREASES AND THE **(SET 2)** BUTTON DECREASES BRIGHTNESS.
NOTE: A (b) IS DISPLAYED ON THE FAR LEFT TO IDENTIFY THIS REGISTER.
- STEP 8:** PRESS THE **(DISPLAY)** BUTTON TO SHOW THE TIME CORRECTION.
THE **(SET 1)** BUTTON INCREASES THE CORRECTION AND THE **(SET 2)** BUTTON DECREASES THE CORRECTION.
THE NUMBER DISPLAYED IS IN SECONDS PER MONTH CORRECTION A MINUS SIGN OVER THE (c) SUBTRACTS SECONDS PER MONTH.
NOTE: A (c) IS DISPLAYED ON THE FAR LEFT TO IDENTIFY THE REGISTER. T
- STEP 9:** PRESS THE **(DISPLAY)** BUTTON TO SHOW THE DISPLAY FORMAT.
(44) FOR HR/MIN AND (46) FOR HR/MIN/SEC
- STEP 10:** PRESS THE **(DISPLAY)** BUTTON TO RETURN TO THE TIME DISPLAY

