PROCESS TAKT TIME **DISPLAYS ELAPSED DOWNTIME AT 0**



BPCN-49940-2P-BOX-IRR-USB-ETHR

SPECIFICATIONS

DIGITAL

DISPLAY:----- 4-DIGIT, 7 SEGMENT RED SUPER BRIGHT LED

CHARACTER HEIGHT:----- 4" (101.6 mm) 9 THOUSAND 9 HUNDRED AND 99

VISIBILITY:----- 250 Ft. (76.2 METERS)


POWER REQUIREMENTS: 100-240V 50~60Hz (12 vdc Switching Transformer)
FRAME:------ 15.25" x 18.25" x 1.5" ALUMINUM (BLACK ANODIZED)


HUMIDITY:----- 0% TO 95% NON-CONDENSING

OPERATING MODE ----- ACTUAL COUNT UP BY 1 VIA 15 FT SWITCH BOX. PROCESS TIME COUNTS

DOWN TO 0. AT 0. DISPLAYS ELAPSED DOWN TIME; USB TO PC CONNECTION AND ETHERNET

CONNECTION FOR WEB-BASED INTERFACE FOR HISTORICAL DATA






FEATURE: View All Devices Remotely via Local Network*

* Requires Ethernet to Local Network connection. WIFI connection available upon request for additional cost.

Smart efficiency displays can be connected to the same network and assigned individual IP addresses via DHCP server. Access each device individually via a secure Linux-based web browser page or monitor all devices on the network on master device.

What if the master device is offline?

Don't worry, you will still be to access the secondary devices individually and can quickly set up one of the secondary devices as a new master.



FEATURE: Schedule Up to 3 Shifts and 100+ Events/Breaks

Set Beginning & End of Shifts

Save a bit of time from resetting devices early in the morning and from recording data manually at the end of each shift by using rules.

When a shift begins, all metrics will be reset to 0 or their starting value.

When a shift ends, metrics (aside from the Actual count) will be frozen and a record of data will be saved for future export via .csv file. Set up email notifications to have a snapshot of the data sent directly to your inbox at the end of each shift.



Schedule Breaks into your System


Events on the Smart Efficiency System allow you to set up scheduled breaks. During scheduled breaks, goal timer will be paused. Connect an Andon light or buzzer to remind employees on the work floor to take a break when they should.



FEATURE: Email Notifications


Aside from End of Day emails, managers and leaders can receive instantaneous email alerts when production is down.

For example, use rules to send an email when a machine's downtime is over 30 minutes. Then, escalate the issue if the downtime is over 1 hour by sending an email directly to the supervisor.



FEATURE: Historical Data Export

Track and download up to 6 months or 40,000 lines of historical data for each device in .CSV format.



FEATURE: Custom Live Data View

Sometimes, supervisors need to track KPIs that don't necessarily need to be shown to all employees on the floor. The Custom Live Data view allows people in charge to view all the relevant metrics that aren't on the physical scoreboard. Values and start times for timers can also be quickly set up via Live Data view.

